

M1: Pump motor
M2: Drive motor
M3: Steering motor
Dw1: Angle sensor
Dw2: Throttle
B1: Steering motor encode
B2: Drive motor encode

SA1: Emergency stop switch
SA2: Key switch
SA3: Forward switch
SA4: Backward switch
SQ1: Interlock switch
SB1: Horn switch
SB2: Fork fall switch

SB3: Turtle switch
SB4: Fork lift switch
SB6: EMR. switch
K1: Lift limit switch
JS1: Steering proximity switch
KM1: Pump motor contactor
KM2: Drive motor contactor

PB: BDI
YV2: Fall electromagnetic valve
YB: Brake coil
TMC: Steering controller

